

NAME  
FINISH  
APPLICATION  
BASE  
SQ FT

## PENETRATING

<b>PROSOCO CONCRETE PROTECTOR SB</b> 	<b>AMERIPOLISH SR2</b> 	<b>HUSQVARNA HIPERGUARD</b> 	<b>COVAL POLISHED CONCRETE SEALER</b> 
<b>HIGH GLOSS</b>	<b>GLOSS</b>	<b>GLOSS</b>	<b>HIGH GLOSS</b>
APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH DIAMOND IMPREGNATED PAD #3000 OR HIGHER	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP <small>BROOM FINISH: APPLY AFTER 7 DAYS</small>  BURNISH WITH DIAMOND IMPREGNATED PAD #3000 OR HIGHER	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH HOGSHAIR PAD	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH DIAMOND IMPREGNATED PAD #1500 OR HIGHER
SOLVENT	SOLVENT	WATER	SOLVENT
2500 SQ FT/GAL	2500 SQ FT/GAL	2500 SQ FT/GAL	2500 SQ FT/GAL

## SEMI-PENETRATING

<b>PROSOCO LS GUARD</b> 	<b>SCOFIELD FORMULA 1 GUARD-W</b> 	<b>AMERIPOLISH 3DSP E</b> 	<b>ENDURABLE POLISH PROTECTOR</b> 	<b>CONVERGENT PENTRA-FINISH HG</b> 
<b>HIGH GLOSS</b>	<b>GLOSS</b>	<b>GLOSS</b>	<b>GLOSS</b>	<b>HIGH GLOSS</b>
APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH DIAMOND IMPREGNATED PAD #1500 OR HIGHER	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH DIAMOND IMPREGNATED PAD #1500 OR HIGHER	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH DIAMOND IMPREGNATED PAD #1500 OR HIGHER	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH DIAMOND IMPREGNATED PAD #1500 OR HIGHER	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH HOGS HAIR OR DIAMOND IMPREGNATED PAD
LITHIUM SILICATE	WATER	WATER	WATER	WATER
1500 SQ FT/GAL	2000 SQ FT/GAL	2000 SQ FT/GAL	2000 SQ FT/GAL	2000 SQ FT/GAL

## TOPICAL (OUTDOOR/INDOOR)

<b>PROSOCO POLISHGUARD</b> 	<b>HUSQVARNA HIPERSEAL</b> 	<b>ENDURABLE F1 SEALER</b> 	<b>ENDURABLE SEALER</b> 
<b>HIGH GLOSS</b>	<b>GLOSS</b>	<b>GLOSS</b>	<b>MATTE OR GLOSS</b>
APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH WHITE OR HOGSHAIR PAD	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP  BURNISH WITH WHITE OR HOGSHAIR PAD	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER WITH A DAMP MICROFIBER MOP OR ROLLER  BURNISH WITH WHITE OR HOGSHAIR PAD	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER OR SPRAY AND MICROFIBER  BURNISH WITH WHITE OR HOGSHAIR PAD
WATER	WATER	ACRYLIC-WATER	WATER
800 SQ FT/GAL	800 SQ FT/GAL	800 SQ FT/GAL	800 SQ FT/GAL

## TOPICAL (OUTDOOR)

<b>AMERIPOLISH X-LINK WB</b> 	<b>LATICRETE L&amp;M LUMISEAL FX</b> 	<b>LATICRETE L&amp;M LUMISEAL PLUS</b> 	<b>SCOFIELD SELECTSEAL PLUS</b> 	<b>SCOFIELD CURESEAL-W</b> 
<b>MATTE</b>	<b>MEDIUM GLOSS</b>	<b>HIGH GLOSS</b>	<b>GLOSS</b>	<b>SEMI-GLOSS</b>
APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP OR ROLLER ON BROOM FINISHED SURFACES	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND A DAMP MICROFIBER MOP	<small>FRESH CONCRETE: WET SURFACE AND BROOM OUT ANY EXCESS WATER. USE A LOW PRESSURE SPRAYER THEN ROLL ON.  EXISTING CONCRETE: CLEAN AND DEGREASE SURFACE OF OIL AND DEBRIS. USE A LOW PRESSURE SPRAYER AND ROLL ON.</small>	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND ROLL ON	APPLY TO A CLEAN SURFACE WITH LOW PRESSURE SPRAYER AND ROLL ON
WATER	WATER	SOLVENT	WATER	WATER
400 SQ FT/GAL	400 SQ FT/GAL	400 SQ FT/GAL	400 SQ FT/GAL	400 SQ FT/GAL